

# Door Dimensions & Rough Opening Guide

*Net Frame Dimension (NFD) WIDTH =  
DOOR WIDTH + 1 11/16" (1.6875)*

*Net Frame Dimension (NFD) HEIGHT =  
DOOR HEIGHT + 1 5/8" (1.6250)*

*ROUGH OPENING (RO) WIDTH =  
NFD WIDTH + 1/2" (0.5000)*

*ROUGH OPENING (RO) HEIGHT =*

Opening

Jamb

Door

RO Height =  
NFD Height + 1/2" (0.5000)

